

## **How to Setup Sync Cables**

In this application document, you will find instructions to set up your pair of Chronos High-Speed Cameras

## Method:

To let two Chronos high-speed cameras communicate with each other, do the following simple steps:

- 1. Take one end of the connecting cable and insert it into the side panel of the camera, the black or green connector.
- 2. The end of the cable can only go in one way. If it does not fit easily rotate it 180 degrees and insert it.
- 3. Do the same with the other end.

Once the connecting cable is in place you can make the two cameras communicate with each other.

Please refer to our <u>triggering tutorial</u>. It describes ways to synchronize the Chronos HS cameras either with a trigger switch cable or with an external device.

Note: Sync Cable works for both, 1.4 and 2.1-HD High-Speed Cameras




Figure 1. Left. One end of the connecting cable. Right. Side panel of a Chronos camera showing the location of the port for the connecting cable.



